

# How to look after me...

- Position me out of direct drafts i.e. open window as this will affect the ability of the wax melting.
- My tealight cup is removable for easy lighting and replacement of tealights. Lighting while in position with supplied matches will blacken glass wax dish.
- To clean my glass wax dish, use a damp cloth (remember to do this when the dish is cool).
- Once I'm secured in a place of your choice, I can easily be removed for cleaning or polishing. Just remove my two screws, (one on the side of the top of the clamp and the other on the side of the bottom of the clamp) and my clamp body will stay in place on the wall.
- Spares and accessories for me can be sourced from [@TheAnnexAccessories](#) if you need them.

## SAFETY TIPS:

- Never leave me alight unattended.
- Keep me out of reach of small children and pets.